

85

TECHNICAL SERVICE PARTS

STYLE 3480, 3482

80

SEE ELEVATION DETAIL

PRODUCT STREAMMASTER II

(103)

2

IF AN ITEM IS NOTED AS "NOT FIELD REPAIRABLE", OR YOU WISH TO RETURN AN ITEM TO AKRON BRASS FOR SERVICE PLEASE GO ONLINE TO, **ONLINEREPAIR.AKRONBRASS.COM**

(133)

(105)

105) 6 18

 $125 \frac{1}{4X}$

3

(134)

OPTIONAL OUTLET

ADAPTER

SCALE 0.500

(132)

 Chg.
 Date

 28
 04-21

 29
 08-21

ASSEMBLY NOTES:

USE PARKER O-LUBE ON ALL O-RINGS AND MATING SURFACES UNLESS OTHERWISE NOTED.

/1 USE PERMABOND LM113 OR LOCTITE 222.

 $\stackrel{\textstyle 2}{}$ USE PRIMER T AND PERMABOND HH120 OR LOCTITE 277.

3 USE MOBILITH SHC460.

4 dimple at assembly.

6 USE PERMABOND LH050 OR LOCTITE 592.

8 GENERAL DEPICTION SEE BILL OF MATERIAL.

9 ALIGN BALL IN HOLE. TIGHTEN PLUG UNTIL TOUCHES
BALL. THEN BACK OUT PLUG 1/4-1/2 TURN.

ASSEMBLE SOUTH POLE OF MAGNET ON SAME SIDE AS DRILL POINT. USE PERMABOND 200 TO HOLD MAGNET IN PLACE. DRILL POINT SHOULD BE DOWN WHEN JOINT IS AT ZERO POSITION.

1 LOCATION OF PERMANENT STOP.

13 USE PRIMER T AND LOCTITE 680.

14 OPTIONAL HANDWHEEL AS SPECIFIED

15 CAN NOT BE USED WITH HANDWHEEL OPTION

THOROUGHLY CLEAN THREADS OF PLUG
AND MATING PART THEN APPLY LOCTITE 425.


1 USE SPECIAL SLIDER 125790, ITEM 22.


18 AS SPECIFIED.

19 TIGHTEN TO 35in-lbs MAX.

TIGHTEN TO 30in-lbs

STAKE AT ASSEMBLY





	ADJUSTABLE ROTATION STOP LOCATIONS 99				
	ANGLE OF	STOP LOCATIONS			
	ROTATION				
	$\pm 90^{\circ}$ (STD)	2,6 (SHOWN)			
	$\pm 45^{\circ}$	1,7			
	±22.5° 17	1,7			
	$\pm 135^{\circ}$	3.5			
	$\pm 177^{\circ}$	PERMANENT STOP ONLY			
	ALL OTHER LOCATIONS 98				

PHONE: 800.228.1161 | www.akronbrass.com

WARRANTY AND DISCLAIMER*: We warrant Akron Brass products for a period of five (5) years* after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service. We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty. *Unless otherwise provided herein. Akron Brass industrial electronic components & the Severe-Duty Monitor have a one (1) year warranty. Select Akron Brass handline nozzles and valves carry a ten (10) year warranty. Scene Star Lights carry a five (5) year warranty. Honda products have the manufacturers' warranty and Akron Brass disclaims any warranty in respect of those products.

© 2016 Akron Brass Company. All rights reservered. No portion of this can be reproduced without the express written consent of the Akron Brass Company.

Parts List Sheet:

AKRON® STYLE 3480, 3482

 $(117)_{19}$

(135)

(106)

TECHNICAL SERVICE PARTS

^[58]

(36)

 $(38)_{\underline{3}}$

 $(89)_{3}$

 $(40)_{3}$

(37)

49

 $(50)_{\hat{3}}$

(42)

(52)(53)(90)(91)/3

(52)(53)(91)(92)(93)(3)

 $44)_{\hat{3}}$

³⁷

 $(135)_{19}$

 $(113)_{15}$

 $(111)_{15}$

 $(135)_{19}$

 $(112)_{\underline{15}}$

 $(115)_{15}$


1116

(122)

PRODUCT STREAMMASTER II

IF AN ITEM IS NOTED AS "NOT FIELD REPAIRABLE", OR YOU WISH TO RETURN AN ITEM TO AKRON BRASS FOR SERVICE PLEASE GO ONLINE TO, **ONLINEREPAIR.AKRONBRASS.COM**

Chg. Date 28 04-21 29 08-21



ASSEMBLY NOTES:

USE PARKER O-LUBE ON ALL O-RINGS AND MATING SURFACES UNLESS OTHERWISE NOTED.

/1 USE PERMABOND LM113 OR LOCTITE 222.

2 USE PRIMER T AND PERMABOND HH120 OR LOCTITE 277.

3 USE MOBILITH SHC460.

4 DIMPLE AT ASSEMBLY.

6 USE PERMABOND LH050 OR LOCTITE 592.

8 GENERAL DEPICTION SEE BILL OF MATERIAL.

ALIGN BALL IN HOLE. TIGHTEN PLUG UNTIL TOUCHES BALL. THEN BACK OUT PLUG 1/4-1/2 TURN.

ASSEMBLE SOUTH POLE OF MAGNET ON SAME SIDE AS DRILL POINT. USE PERMABOND 200 TO HOLD MAGNET IN PLACE. DRILL POINT SHOULD BE DOWN WHEN JOINT IS AT ZERO POSITION.


1 LOCATION OF PERMANENT STOP.

13 USE PRIMER T AND LOCTITE 680.

14 OPTIONAL HANDWHEEL AS SPECIFIED

√15 CAN NOT BE USED WITH HANDWHEEL OPTION

16 THOROUGHLY CLEAN THREADS OF PLUG AND MATING PART THEN APPLY LOCTITE 425.



ANGLE OF STOP LOCATIONS **ELEVATION** -45° , $+90^{\circ}$ (STD) PT B -45° , $+45^{\circ}$ PT A -45° , + 120 $^{\circ}$ NO STOPS -15° , $+45^{\circ}$ PT A, PT C -15° , $+90^{\circ}$ PT B, PT C

| ELEVATION STOP LOCATIONS $(100)_1$

ALL OTHER LOCATIONS

-15°, +120°

(101)

PT C

(26)

ELEVATION DETAIL

SET SCREW SUPPLIED WITH PULLEY

 $(94)_{3}$

 $(55)_{3}$

13 BETWEEN PULLEY **AND SHAFT**

PHONE: 800.228.1161 | www.akronbrass.com

WARRANTY AND DISCLAIMER*: We warrant Akron Brass products for a period of five (5) years* after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service. We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty. *Unless otherwise provided herein. Akron Brass industrial electronic components & the Severe-Duty Monitor have a one (1) year warranty. Select Akron Brass handline nozzles and valves carry a ten (10) year warranty. Scene Star Lights carry a (6) year warranty. Weldon products have a two (2) year warranty from date of manufacture (excluding consumable components). Select Weldon LED products carry a five (5) year warranty. Honda products have the manufacturers' warranty and Akron Brass disclaims any warranty in respect of those products.

© 2016 Akron Brass Company. All rights reservered. No portion of this can be reproduced without the express written consent of the Akron Brass Company.

73

(28

88

96

Parts List Sheet:



SET SCREW SUPPLIED

BETWEEN PULLEY AND SHAFT

62

WITH PULLEY

TECHNICAL SERVICE PARTS

(48) 51) 52) 53) 55)

STYLE 3480, 3482

PRODUCT STREAMMASTER II

ROTATION DETAIL

54

⁽⁵⁶⁾

© 2016 Akron Brass Company. All rights reservered. No portion of this can be reproduced without the express written consent of the Akron Brass Company.

IF AN ITEM IS NOTED AS "NOT FIELD REPAIRABLE", OR YOU WISH TO RETURN AN ITEM TO AKRON BRASS FOR SERVICE PLEASE GO ONLINE TO, **ONLINEREPAIR.AKRONBRASS.COM**

(35)

(36)

38

(130)

(27)

49

42

(50

(28)

(39)

Chg. Date 28 04-21 29 08-21

ASSEMBLY NOTES:

USE PARKER O-LUBE ON ALL O-RINGS AND MATING SURFACES UNLESS OTHERWISE NOTED.

 $\angle 1$ use Permabond LM113 or Loctite 222.

 $\angle 2$ USE PRIMER T AND PERMABOND HH120 OR LOCTITE 277.

✓3 USE MOBILITH SHC460.

4 DIMPLE AT ASSEMBLY.

6\ use permabond lh050 or loctite 592.

/8\ GENERAL DEPICTION SEE BILL OF MATERIAL.

9\ ALIGN BALL IN HOLE. TIGHTEN PLUG UNTIL TOUCHES BALL. THEN BACK OUT PLUG 1/4-1/2 TURN.

10 ASSEMBLE SOUTH POLE OF MAGNET ON SAME SIDE AS DRILL POINT. USE PERMABOND 200 TO HOLD MAGNET IN PLACE. DRILL POINT SHOULD BE DOWN WHEN JOINT IS AT ZERO POSITION.

1 LOCATION OF PERMANENT STOP.

13 USE PRIMER T AND LOCTITE 680.

14 OPTIONAL HANDWHEEL AS SPECIFIED

15 CAN NOT BE USED WITH HANDWHEEL OPTION

16 THOROUGHLY CLEAN THREADS OF PLUG AND MATING PART THEN APPLY LOCTITE 425.


/1入 USE SPECIAL SLIDER 125790, ITEM 22.

18 AS SPECIFIED.

19 TIGHTEN TO 35in-lbs MAX.

20 TIGHTEN TO 30in-lbs

∕2↑ STAKE AT ASSEMBLY



PHONE: 800.228.1161 | www.akronbrass.com

WARRANTY AND DISCLAIMER*: We warrant Akron Brass products for a period of five (5) years* after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service. We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty. *Unless otherwise provided herein. Akron Brass industrial electronic components & the Severe-Duty Monitor have a one (1) year warranty. Select Akron Brass handline nozzles and valves carry a ten (10) year warranty. Scene Star Lights carry a (6) year warranty. Weldon products have a two (2) year warranty from date of manufacture (excluding consumable components). Select Weldon LED products carry a five (5) year warranty. Honda products have the manufacturers' warranty and Akron Brass disclaims any warranty in respect of those products.

60

(29)

123965

Parts List Sheet:



TECHNICAL SERVICE PARTS

STYLE 3480, 3482


PRODUCT STREAMMASTER II

IF AN ITEM IS NOTED AS "NOT FIELD REPAIRABLE", OR YOU WISH TO RETURN AN ITEM TO AKRON BRASS FOR SERVICE PLEASE GO ONLINE TO, **ONLINEREPAIR.AKRONBRASS.COM**

 Chg.
 Date

 28
 04-21

 29
 08-21



PHONE: 800.228.1161 | www.akronbrass.com

WARRANTY AND DISCLAIMER*: We warrant Akron Brass products for a period of five (5) years* after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service. We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty. *Unless otherwise provided herein. Akron Brass industrial electronic components & the Severe-Duty Monitor have a one (1) year warranty. Select Akron Brass handline nozzles and valves carry a ten (10) year warranty. Scene Star Lights carry a five (5) year warranty. Honda products have the manufacturers' warranty and Akron Brass disclaims any warranty in respect of those products.

© 2016 Akron Brass Company. All rights reservered. No portion of this can be reproduced without the express written consent of the Akron Brass Company.

Parts List Sheet:



TECHNICAL SERVICE PARTS

STYLE 3480, 3482

PRODUCT STREAMMASTER II

IF AN ITEM IS NOTED AS "NOT FIELD REPAIRABLE", OR YOU WISH TO RETURN AN ITEM TO AKRON BRASS FOR SERVICE PLEASE GO ONLINE TO, **ONLINEREPAIR.AKRONBRASS.COM**

Chg. Date
28 04-21
29 08-21


	EM IO.	DESCRIPTION	PART NO.	QTY 3480	QTY 3482		EM O.	DESCRIPTION PA	ART NO.	QTY 3480	QTY 3482
1		BASE 3"	128384	-	1	68	<u> </u>	WASHER #8	84123	6	6
1		BASE 4"	128382	1	-	69			65064	4	4
1		BASE DN100	128386	1	-	70			430005	1	1
1		BASE DN80	128388	_	1	71			65178	2	2
1		BASE AERIAL VALVE MANIFOLD	127383	1	1	73			23935	1	1
2		ELBOW INLET	126973	1	1	74			65310	7	7
3		ELBOW OUTLET 3.5" NH	128246	1	-	75			23934	1	1
3		ELBOW OUTLET 2.5" NH	124138	_	1	76			65030	8	8
10	С	O-RING 2-343	757319	1	1	77	C		03058	1	1
11	C	O-RING 2-241	757210	1	1	78	C		03057	1	1
12	C	O-RING 2-158	757326	1	1	79	C	O-RING 2-242 7	57073	1	1
13	A,C	3/8" BALL BEARING	-	75	75	80	C		57076	1	1
14	C	PLUG	742112	2	2	81	C		57446	1	1
15	C	PLUG W/HOLE	742123	2	2	82	C		57376	1	1
16		GREASE FITTING	713191	4	4	83			58326	1	1
20		FLANGE ROTATION	712297	1	1	84			31127	1	1
21		SCREW 10-24 X 3/4	767086	8	8	85			65179	2	2
22		SLIDER	125789	1	1	88	Е		57358	1	1
22		SLIDER(± 22.5° ONLY)	125790	1	1	89	D		03995	1	1
26		MOTOR S/A 12V	34800002	1	1	90	H		69949	1	1
26		MOTOR S/A 24V	34800003	1	1	90	L		68470	1	1
27	*,C	O-RING 2-029	757056	2	2	91	 Н,L		18339	8	8
28	, c	SCREW 6-32 X 1/2	765052	8	8	92	•		42241	1	1
29	F,M	BELT 85 TEETH	803061	1	1	93	H,L		03064	1	1
35	G	BUSHING	803063	1	1	94	F		69948	1	1
36	D,G	SPRING	769276	2	2	95	 E		45241	1	1
37	D,G	THRUST WASHER	784121	8	8	96	 E		303062	1	1
38	D,G	NEEDLE BEARING	703453	4	4	97			07016	1	1
39	D,G	WOODRUFF KEY	727025	2	2	98			44337	4	4
40	D,G	WORM GEAR	718273	2	2	99			69498	3	3
42	D,G	SCREW 10-24 X 3/8	767029	8	8	100	M		69843	2	2
43	G G	O-RING 2-036	757312	1	1	101	171		45187	2	2
44	ı	GEAR	718337	1	1	103			45285	-	1
46	K	SHAFT	769951	1	1	103			44551	1	_
47	K,G	WORM GEAR	718303	1	1	104			36052	4	4
48	K,G	ROLL PIN 1/16 x 3/8	744341	1	1	105			44009	2	2
49	D,G	PLUG	123938	2	2	105			118323	1	1
50		BUSHING	703819	2	2	105			18322	1	1
51	K	PLANET GEAR	718262	3	3	106			07087	1	1
52		BUSHING	703989	 12	12	111			07139	2	2
53		SCREW SHOULDER	803059	11	11	112			21291	2	2
54	K	GEAR	718338	1	1	113			44339	2	2
55	E,K	BUSHING	803065	1	1	114			29117	2	2
56	E,IX	SHAFT	769950	1	1	115			758203	6	6
57	F,M	PULLEY	745240	1	1	116			65143	2	2
58		O-RING 2-112	757313	2	2	117			61103	1	1
59		BEARING	704395	1	1	118			520003	1	1
60	•	O-RING 2-164	757486	1	1	118			520003	1	1
61	1 ,171	COVER-ROTATION	807017	1	1	119			63035	2	7
62		SCREW 10-24 X 1-1/4	767100	2	7	120			84072	2	7
65	В	WORM GEAR	718302	1	1	120			07436	2	7
66	В	O-RING 2-120	757020	1	1	121			07430	1	1
67	В	MAGNET	737020	1	1	١٧٨		CADLE CLAIMI 3/10	OFC 10	I	ı
			צנוונו	I	I						
PHC)N⊢. 8	300.228.1161 www.akronbrass.com									


ITEM NO.		DESCRIPTION	PART NO.	QTY 3480	QTY 3482				
123		CABLE CLAMP 1/2	707188	1	1				
124		O-RING 2-136	757083	1	1				
125		SCREW SET 5/16-18 x 1/4	765071	4	4				
126		PLUG 4PIN DEUTSCH	745230	1	1				
127		POWER HARNESS U2 8'	721682	2 1 1					
127		POWER HARNESS U2 4'	721695	1	1				
127		POWER HARNESS U2 10'	721696	1	1				
130		MOTOR S/A 12V	34800022	1	1				
130		MOTOR S/A 24V	34800023	1	1				
131		EXTERNAL ANTENNA KIT (OPTIONAL) 2.4 GHz	34800057	1	1				
132		OUTLET ADAPTER 2.50"BSP	104359	1	1				
133		ADAPTER GASKET	717043	1	1				
134		SCREW SOCKET HEAD CUP POINT SET 1/4-20 x 1/4"	765002	1	1				
135		SCREW BTTN NYLON PATCH 10-24 X 3/8	761104	4	4				
OPTIONAL HANDWHEEL									
56	M	ROTATION SHAFT	768469	1	1				
90	L	ELEVATION SHAFT	768470	1	1				
116		SCREW BUTTON HEAD CAP 10-24 X 3/8	765143	4	4				
202		HANDWHEEL (STANDARD)	721745	2	2				
203		HANDWHEEL (OPTIONAL, ROTATION ONLY)	127995	1	1				
А		KIT OF 50 BALLS	109342						
В		WORM GEAR SENSOR KIT	34800014						
С		FIELD SERVICE KIT	92200001						
D		ELEVATION ACTUATOR REPAIR KIT	34800076						
E		ELEVATION BELT REPAIR KIT	34800077						
F		ROTATION BELT REPAIR KIT	34800078						
G		ROTATION ACTUATOR REPAIR KIT	34800079						
***, H		PLANETARY GEAR ELEVATION WITH SHAFT	34800112						
***, K		PLANETARY GEAR ROTATION	34800113						
***, L		PLANETARY GEAR ELEVATION HANDWHEEL VERSION	34803123						


- * INCLUDED WITH MOTOR S/A ITEMS 26 AND 130.
- ** REPLACES SHAFT WITHOUT HANDWHEEL.

ROTATION BELT REPAIR KIT HANDWHEEL VERSION

*** USE ALL GEARS PROVIDED IN KIT.







34800096

PHONE: 800.228.1161 | www.akronbrass.com

WARRANTY AND DISCLAIMER*: We warrant Akron Brass products for a period of five (5) years* after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service. We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty. *Unless otherwise provided herein. Akron Brass industrial electronic components & the Severe-Duty Monitor have a one (1) year warranty. Select Akron Brass handline nozzles and valves carry a ten (10) year warranty. Scene Star Lights carry a five (5) year warranty. Honda products have the manufacturers' warranty and Akron Brass disclaims any warranty in respect of those products.

© 2016 Akron Brass Company. All rights reservered. No portion of this can be reproduced without the express written consent of the Akron Brass Company.

Parts List Sheet: